

<div>CONTENTS</div> <table><tr><td>INTRODUCTION</td><td>INSTALLATION</td></tr><tr><td>1</td><td>3</td></tr><tr><td>STANDALONE MODE</td><td>CONTROLLER MODE</td></tr><tr><td>5</td><td>11</td></tr><tr><td>WIEGAND READER MODE</td><td>ADVANCED APPLICATION</td></tr><tr><td>13</td><td>15</td></tr></table>	INTRODUCTION	INSTALLATION	1	3	STANDALONE MODE	CONTROLLER MODE	5	11	WIEGAND READER MODE	ADVANCED APPLICATION	13	15	<div>INTRODUCTION</div> <p>The XK Series Device is a single door multifunction standalone access controller or a Wiegand output reader. It uses Atmel MCU assuring stable performance. The operation is very user-friendly, and low-power circuit makes it long service life.</p> <p>The XK Series Device supports 1,000 users (998 common users + 2 panic users), all user data can be transferred from one to another. It supports multi access modes in either card access, PIN access, Card + PIN access, or multi cards/PINs access. It has extra features including block enrollment, interlocked, Wiegand 26-37 bits interface, etc.</p> <div>Features</div> <ul style="list-style-type: none">> Bluetooth Module(Optional), to connect mobile for opening door> Fashion design, all-metal key button> Metal Case, Anti-vandal> Waterproof, conforms to IP66> One relay, keyboard programmer> 1,000 users (998 common users + 2 panic users)> PIN length: 4-6 digits> Card type: EM version: 125KHz EM card HID & EM version: 125KHz HID & EM cards> Wiegand 26-37 bits input & output> Can be used as Wiegand reader with LED & buzzer output> Card block enrollment> Tri-colour LED status display> Integrated alarm & buzzer output> Pulse mode, Toggle mode> User data can be transferred> 2 devices can be interlocked for 2 doors> Built in light dependent resistor (LDR) for anti tamper> Backlit keypad> Low temperature resistance(-40 °C)> Voltage: 12-28V AC/DC <div>Specifications</div> <table><tr><td>User Capacity</td><td>1000</td></tr><tr><td>Common User</td><td>998</td></tr><tr><td>Panic User</td><td>2</td></tr><tr><td>Operating Voltage</td><td>12-28V AC/DC</td></tr><tr><td>Idle Current</td><td>< 35mA</td></tr></table> <div>- 01 -</div>	User Capacity	1000	Common User	998	Panic User	2	Operating Voltage	12-28V AC/DC	Idle Current	< 35mA	<div>INSTALLATION</div> <p>> Remove the back cover from the unit</p> <p>> Drill 2 holes(A,C) on the wall for the screws and one hole for the cable</p> <p>> Knock the supplied rubber bungs to the screw holes(A,C)</p> <p>> Fix the back cover firmly on the wall with 4 flat head screws</p> <p>> Thread the cable through the cable hole(B)</p> <p>> Attach the unit to the back cover</p> <div>Wide</div> <div>Slim</div> <div>Wiring</div> <table><tr><th>Wire Color</th><th>Function</th><th>Notes</th></tr><tr><td>Red</td><td>AC/DC</td><td>12-28V AC/DC Regulated Power Input</td></tr><tr><td>Black</td><td>AC/DC</td><td>12-28V AC/DC Regulated Power Input</td></tr><tr><td>Pink</td><td>GND</td><td>Negative Pole</td></tr><tr><td>Blue</td><td>Relay NO</td><td>Normally Open Relay Output (install diode provided)</td></tr><tr><td>Purple</td><td>Relay Common</td><td>Common Connection for Relay Output</td></tr></table> <div>Connection Diagram</div> <div>Attention: Install a 1N4004 or equivalent diode is needed when use a common power supply, or the keypad might be damaged. (1N4004 is included in the packing)</div> <div>- 03 -</div>	Wire Color	Function	Notes	Red	AC/DC	12-28V AC/DC Regulated Power Input	Black	AC/DC	12-28V AC/DC Regulated Power Input	Pink	GND	Negative Pole	Blue	Relay NO	Normally Open Relay Output (install diode provided)	Purple	Relay Common	Common Connection for Relay Output	<div>Set the Working Mode</div> <p>Notes: the XK Series Device has 3 working modes: Standalone Mode, Controller Mode, Wiegand Reader Mode, choose the mode you use. (Factory default is Standalone Mode / Controller Mode)</p> <table><tr><th>Programming Step</th><th>Keystroke Combination</th></tr><tr><td>1. Enter Program Mode</td><td>* (Master Code) #</td></tr><tr><td>2. Standalone/Controller Mode</td><td>7 2 # (Factory default)</td></tr><tr><td>3. Exit</td><td>7 3 #</td></tr><tr><td></td><td>*</td></tr></table> <div>STANDALONE MODE</div> <p>The XK Series Device can be worked as Standalone Reader for single door. (Factory default mode)---7 2 #</p> <div>Connection Diagram</div> <div>Common Power Supply</div> <div>Attention: Install a 1N4004 or equivalent diode is needed when use a common power supply, or the keypad might be damaged. (1N4004 is included in the packing)</div> <div>- 05 -</div>	Programming Step	Keystroke Combination	1. Enter Program Mode	* (Master Code) #	2. Standalone/Controller Mode	7 2 # (Factory default)	3. Exit	7 3 #		*	<div>Access Control Power Supply:</div> <div>Programming</div> <p>Notes:</p> <p>> User ID number: Assign a user ID to the access card / PIN in order to track it. The common user ID number can be any number from 0~997, the panic user ID is from 998~999. IMPORTANT: User IDs do not have to be proceeded with any leading zeros. Recording of User ID is critical. Modifications to the user require the User ID be available.</p> <p>> Proximity Card: EM version: 125 KHz industry standard 26bits EM card</p> <p>> HID & EM version: 125 KHz industry standard 26bits HID & EM cards</p> <p>> PIN: Can be any 4~6 digits except 8888 which is reserved</p> <div>- 06 -</div>	<div>Add Common Users</div> <table><tr><th>Programming Step</th><th>Keystroke Combination</th></tr><tr><td>1. Enter Program Mode</td><td>* (Master Code) #</td></tr></table> <div>Add Card User</div> <p>2. Add Card: Using Auto ID (Allows the XK Series Device to assign Card to next available User ID number)</p> <p>OR</p> <p>2. Add Card: Select Specific ID (Allows Master to define a specific User ID to associate the card to)</p> <p>OR</p> <p>2. Add Card: by Card Number</p> <p>OR</p> <p>2. Add Card: Block Enrollment (Allows Master to add up to 998 cards to the Reader in a single step) Takes 2 minutes to program.</p> <table><tr><th>1 (Read Card) #</th><th>* (Read Card) (Old PIN) # (New PIN) # (Repeat New PIN) #</th></tr><tr><td>The cards can be added continuously.</td><td></td></tr><tr><td>1 (User ID) # (Read Card) # (User ID is any number from 0~997)</td><td></td></tr><tr><td>1 (Input 8/10 digits Card number) #</td><td></td></tr><tr><td>1 (User ID) # (Card quantity) # (The first card number) #</td><td></td></tr><tr><td>Cards' number must be consecutive; Card quantity = number of cards to be enrolled.</td><td></td></tr></table> <div>Add PIN User</div> <p>2. Add PIN: Using Auto ID (Allows the XK Series Device to assign PIN to next available User ID number)</p> <p>OR</p> <p>2. Add PIN: Select Specific ID (Allows manager to define a specific User ID to associate the PIN to)</p> <p>3. Exit</p> <table><tr><th>1 (PIN) #</th><th>* (PIN) #</th></tr><tr><td>The PINs can be added continuously. (PIN: 4-6 digits)</td><td></td></tr><tr><td>1 (User ID) # (PIN) #</td><td></td></tr><tr><td>The user ID is any number from 0~997.</td><td></td></tr><tr><td>*</td><td></td></tr></table> <div>Add Panic Users</div> <table><tr><th>Programming Step</th><th>Keystroke Combination</th></tr><tr><td>1. Enter Program Mode</td><td>* (Master Code) #</td></tr><tr><td>2. Add Card:</td><td>1 (User ID) # (Read Card / Input 8/10 digits Card number) #</td></tr><tr><td>2. Add PIN:</td><td>1 (User ID) # (PIN) # (User ID is any number from 998~999)</td></tr><tr><td>3. Exit</td><td>*</td></tr></table> <div>- 07 -</div>	Programming Step	Keystroke Combination	1. Enter Program Mode	* (Master Code) #	1 (Read Card) #	* (Read Card) (Old PIN) # (New PIN) # (Repeat New PIN) #	The cards can be added continuously.		1 (User ID) # (Read Card) # (User ID is any number from 0~997)		1 (Input 8/10 digits Card number) #		1 (User ID) # (Card quantity) # (The first card number) #		Cards' number must be consecutive; Card quantity = number of cards to be enrolled.		1 (PIN) #	* (PIN) #	The PINs can be added continuously. (PIN: 4-6 digits)		1 (User ID) # (PIN) #		The user ID is any number from 0~997.		*		Programming Step	Keystroke Combination	1. Enter Program Mode	* (Master Code) #	2. Add Card:	1 (User ID) # (Read Card / Input 8/10 digits Card number) #	2. Add PIN:	1 (User ID) # (PIN) # (User ID is any number from 998~999)	3. Exit	*
INTRODUCTION	INSTALLATION																																																																																										
1	3																																																																																										
STANDALONE MODE	CONTROLLER MODE																																																																																										
5	11																																																																																										
WIEGAND READER MODE	ADVANCED APPLICATION																																																																																										
13	15																																																																																										
User Capacity	1000																																																																																										
Common User	998																																																																																										
Panic User	2																																																																																										
Operating Voltage	12-28V AC/DC																																																																																										
Idle Current	< 35mA																																																																																										
Wire Color	Function	Notes																																																																																									
Red	AC/DC	12-28V AC/DC Regulated Power Input																																																																																									
Black	AC/DC	12-28V AC/DC Regulated Power Input																																																																																									
Pink	GND	Negative Pole																																																																																									
Blue	Relay NO	Normally Open Relay Output (install diode provided)																																																																																									
Purple	Relay Common	Common Connection for Relay Output																																																																																									
Programming Step	Keystroke Combination																																																																																										
1. Enter Program Mode	* (Master Code) #																																																																																										
2. Standalone/Controller Mode	7 2 # (Factory default)																																																																																										
3. Exit	7 3 #																																																																																										
	*																																																																																										
Programming Step	Keystroke Combination																																																																																										
1. Enter Program Mode	* (Master Code) #																																																																																										
1 (Read Card) #	* (Read Card) (Old PIN) # (New PIN) # (Repeat New PIN) #																																																																																										
The cards can be added continuously.																																																																																											
1 (User ID) # (Read Card) # (User ID is any number from 0~997)																																																																																											
1 (Input 8/10 digits Card number) #																																																																																											
1 (User ID) # (Card quantity) # (The first card number) #																																																																																											
Cards' number must be consecutive; Card quantity = number of cards to be enrolled.																																																																																											
1 (PIN) #	* (PIN) #																																																																																										
The PINs can be added continuously. (PIN: 4-6 digits)																																																																																											
1 (User ID) # (PIN) #																																																																																											
The user ID is any number from 0~997.																																																																																											
*																																																																																											
Programming Step	Keystroke Combination																																																																																										
1. Enter Program Mode	* (Master Code) #																																																																																										
2. Add Card:	1 (User ID) # (Read Card / Input 8/10 digits Card number) #																																																																																										
2. Add PIN:	1 (User ID) # (PIN) # (User ID is any number from 998~999)																																																																																										
3. Exit	*																																																																																										
	<div>Set Strike-out Alarm</div> <p>The strike-out alarm will engage after 10 failed entry attempts (Factory is OFF). It can be set to deny access for 10 minutes after engaging or disengage only after entering a valid card/PIN or Master code.</p> <table><tr><th>Programming Step</th><th>Keystroke Combination</th></tr><tr><td>1. Enter Program Mode</td><td>* (Master Code) #</td></tr><tr><td>2. Strike-Out OFF</td><td>6 0 # (factory default)</td></tr><tr><td>OR</td><td>6 1 # Access will be denied for 10 minutes</td></tr><tr><td>2. Strike-Out ON (Alarm)</td><td>6 2 #</td></tr><tr><td>Set alarm time</td><td>5 (0 ~ 3) # (factory default is 1 minute)</td></tr><tr><td>Enter Master code # or valid user card / PIN to silence</td><td></td></tr><tr><td>3. Exit</td><td>*</td></tr></table> <div>Set Audible and Visual Response</div> <table><tr><th>Programming Step</th><th>Keystroke Combination</th></tr><tr><td>1. Enter Program Mode</td><td>* (Master Code) #</td></tr><tr><td>2. Control Sounds</td><td>OFF = 7 0 # ON = 7 1 #</td></tr><tr><td>2. Control LED</td><td>OFF = 7 4 # ON = 7 5 #</td></tr><tr><td>2. Control Keypad Backlit</td><td>OFF = 7 6 # ON = 7 7 # (Factory defaults are ON)</td></tr><tr><td>3. Exit</td><td>*</td></tr></table> <div>Set Card Reading Type (This step can only be applied to HID & EM version)</div> <table><tr><th>Programming Step</th><th>Keystroke Combination</th></tr><tr><td>1. Enter Program Mode</td><td>* (Master Code) #</td></tr><tr><td>2. Read HID & EM card</td><td>9 3 # (factory default)</td></tr><tr><td>OR</td><td>2. Read EM card ONLY</td></tr><tr><td>2. Read HID card ONLY</td><td>9 4 #</td></tr><tr><td>3. Exit</td><td>*</td></tr></table> <div>- 10 -</div>	Programming Step	Keystroke Combination	1. Enter Program Mode	* (Master Code) #	2. Strike-Out OFF	6 0 # (factory default)	OR	6 1 # Access will be denied for 10 minutes	2. Strike-Out ON (Alarm)	6 2 #	Set alarm time	5 (0 ~ 3) # (factory default is 1 minute)	Enter Master code # or valid user card / PIN to silence		3. Exit	*	Programming Step	Keystroke Combination	1. Enter Program Mode	* (Master Code) #	2. Control Sounds	OFF = 7 0 # ON = 7 1 #	2. Control LED	OFF = 7 4 # ON = 7 5 #	2. Control Keypad Backlit	OFF = 7 6 # ON = 7 7 # (Factory defaults are ON)	3. Exit	*	Programming Step	Keystroke Combination	1. Enter Program Mode	* (Master Code) #	2. Read HID & EM card	9 3 # (factory default)	OR	2. Read EM card ONLY	2. Read HID card ONLY	9 4 #	3. Exit	*	<div>Master Cards Usage</div> <p>Using Master Cards to add and delete card users</p> <p>Add a User</p> <ol style="list-style-type: none">1. (Read Master Add Card)2. (Read User Card)Repeat Step 2 for additional user cards3. (Read Master Delete Card) <p>Delete a User</p> <ol style="list-style-type: none">1. (Read Master Delete Card)2. (Read User Card)Repeat Step 2 for additional user cards3. (Read Master Delete Card) <div>Users Operation & Reset to Factory Default</div> <p>> Open the door: Read valid user card or inputting valid user PIN</p> <p>> Remove Alarm: Read valid user card or inputting valid user PIN, or input Master Code #</p> <p>> To reset to factory default & Add Master Cards: Power off, press the Exit Button, hold it and power on, there will be two beeps, and the LED light turns into yellow, release the exit button, then read any two 125KHz EM cards or HID cards, the LED will turn into red, means reset to factory default successfully. Of the two cards reading, the 1st one is Master Add Card, the 2nd one is the Master Delete Card.</p> <div>Remarks:</div> <p>① If no Master Cards added, must press the Exit Button for at least 10 seconds before release.</p> <p>② Reset to factory default, the user's information is still retained.</p> <div>CONTROLLER MODE</div> <p>The XK Series Device can work as Controller, connected with the external Wiegand reader. (Factory default mode)---7 2 #</p> <div>Programming</div> <p>> Basic Programming is the same as Standalone Mode</p> <p>> There are some exceptions for your attention:</p> <p>The XK Series Device connected with External Card Reader:</p> <ul style="list-style-type: none">- If EM card reader or HID card reader: users can be added/deleted on either the XK Series Device or external reader.- If Mifare reader: users can only be added/deleted on external reader. <div>- 11 -</div>	<div>Connection Diagram</div> <div>Notes:</div> <p>> When set into Wiegand Reader mode, nearly all settings in Controller Model will become invalid. And Brown & Yellow wires will be redefined as below:</p> <ul style="list-style-type: none">- Brown wire: Green LED light control- Yellow wire: Buzzer control <p>> If you need to connect Brown/Yellow wires: When the input voltage for LED is low, the LED will turn into Green; and when the input voltage for Buzzer is low, it will sound.</p> <div>Set Wiegand Output Formats</div> <p>Please set the Wiegand output formats of Reader according to the Wiegand input formats of the Controller.</p> <table><tr><th>Programming Step</th><th>Keystroke Combination</th></tr><tr><td>1. Enter Program Mode</td><td>* (Master Code) #</td></tr><tr><td>2. Wiegand output bits</td><td>8 (26-37) # (factory default is 26 bits)</td></tr><tr><td>2. Wiegand output bits</td><td>8 (4 or 8 or 10) # (factory default is 4 bits)</td></tr><tr><td>3. Exit</td><td>*</td></tr></table> <div>- 13 -</div>	Programming Step	Keystroke Combination	1. Enter Program Mode	* (Master Code) #	2. Wiegand output bits	8 (26-37) # (factory default is 26 bits)	2. Wiegand output bits	8 (4 or 8 or 10) # (factory default is 4 bits)	3. Exit	*	<div>Advanced Application</div> <div>User Information Transfer</div> <p>The XK Series Device supports the User Information Transfer function, and the enrolled user (cards, PINs) can be transferred from one (let's name it Master Unit) to another (let's name it Accept Unit)</p> <div>Connection Diagram:</div> <div>Remarks:</div> <p>> The Master units and Accept units must be XK Series Device or SK2/SK5 or S-X series or Board.</p> <p>> The Master Code of the Master Unit and the Accept Unit must be set to the same.</p> <p>> Program the transfer operation on Master Unit only.</p> <p>> If the Accept Unit is already with the users enrolled, it will be covered after transferring.</p> <p>> For full 1000 users enrolled, the transfer takes 3 minutes.</p> <div>Set Transferring on Master Unit:</div> <table><tr><th>Programming Step</th><th>Keystroke Combination</th></tr><tr><td>1. Enter the programming mode</td><td>* (Master Code) #</td></tr><tr><td>2. Set transferring</td><td>9 6 #</td></tr><tr><td>Within 3 minutes, Green LED shines, after one beep, the LED will turn into Red, which means the users' information has been transferred successfully.</td><td></td></tr><tr><td>3. Exit</td><td>*</td></tr></table> <div>- 15 -</div>	Programming Step	Keystroke Combination	1. Enter the programming mode	* (Master Code) #	2. Set transferring	9 6 #	Within 3 minutes, Green LED shines, after one beep, the LED will turn into Red, which means the users' information has been transferred successfully.		3. Exit	*	<div>Interlock</div> <p>The XK Series Device supports the Interlock function. It is of two keypads for two doors, and mainly used for banks, prisons, and other places where a higher level security is required.</p> <div>Connection Diagram:</div> <div>Remarks:</div> <p>> The Door Contact must be installed and connected as the diagram.</p> <p>Let's name the two Keypads as "A" and "B" for two doors "1" and "2"</p> <p>Step 1: Enroll the users on Keypad A, then transfer the users' information to Keypad B by "User Information Transfer" function.</p> <p>Step 2: Set both of the two Keypads (A and B) to Interlock function</p> <table><tr><th>Programming Step</th><th>Keystroke Combination</th></tr><tr><td>1. Enter Program Mode</td><td>* (Master Code) #</td></tr><tr><td>2. Interlocked-OFF</td><td>9 0 # (factory default)</td></tr><tr><td>OR</td><td>9 1 #</td></tr><tr><td>2. Interlocked-ON</td><td>9 1 #</td></tr><tr><td>3. Exit</td><td>*</td></tr></table> <div>The interlock operation is finished. When and only door 2 is closed, the user can read the valid card or input PIN on Keypad A, door 1 will open; then when and only door 1 closed, read valid card or input PIN on Keypad B, door 2 will open.</div> <div>- 17 -</div>	Programming Step	Keystroke Combination	1. Enter Program Mode	* (Master Code) #	2. Interlocked-OFF	9 0 # (factory default)	OR	9 1 #	2. Interlocked-ON	9 1 #	3. Exit	*														
Programming Step	Keystroke Combination																																																																																										
1. Enter Program Mode	* (Master Code) #																																																																																										
2. Strike-Out OFF	6 0 # (factory default)																																																																																										
OR	6 1 # Access will be denied for 10 minutes																																																																																										
2. Strike-Out ON (Alarm)	6 2 #																																																																																										
Set alarm time	5 (0 ~ 3) # (factory default is 1 minute)																																																																																										
Enter Master code # or valid user card / PIN to silence																																																																																											
3. Exit	*																																																																																										
Programming Step	Keystroke Combination																																																																																										
1. Enter Program Mode	* (Master Code) #																																																																																										
2. Control Sounds	OFF = 7 0 # ON = 7 1 #																																																																																										
2. Control LED	OFF = 7 4 # ON = 7 5 #																																																																																										
2. Control Keypad Backlit	OFF = 7 6 # ON = 7 7 # (Factory defaults are ON)																																																																																										
3. Exit	*																																																																																										
Programming Step	Keystroke Combination																																																																																										
1. Enter Program Mode	* (Master Code) #																																																																																										
2. Read HID & EM card	9 3 # (factory default)																																																																																										
OR	2. Read EM card ONLY																																																																																										
2. Read HID card ONLY	9 4 #																																																																																										
3. Exit	*																																																																																										
Programming Step	Keystroke Combination																																																																																										
1. Enter Program Mode	* (Master Code) #																																																																																										
2. Wiegand output bits	8 (26-37) # (factory default is 26 bits)																																																																																										
2. Wiegand output bits	8 (4 or 8 or 10) # (factory default is 4 bits)																																																																																										
3. Exit	*																																																																																										
Programming Step	Keystroke Combination																																																																																										
1. Enter the programming mode	* (Master Code) #																																																																																										
2. Set transferring	9 6 #																																																																																										
Within 3 minutes, Green LED shines, after one beep, the LED will turn into Red, which means the users' information has been transferred successfully.																																																																																											
3. Exit	*																																																																																										
Programming Step	Keystroke Combination																																																																																										
1. Enter Program Mode	* (Master Code) #																																																																																										
2. Interlocked-OFF	9 0 # (factory default)																																																																																										
OR	9 1 #																																																																																										
2. Interlocked-ON	9 1 #																																																																																										
3. Exit	*																																																																																										
					<div>Waterproof Standalone/Controller/Reader</div> <div>Wide</div> <div>Slim</div> <div>User Manual</div>																																																																																						